

Quick Setup

This guide provides how to boot the ZVC system and initialize the system for administrators.

1. Initial Setup

Once the MCore/MCore Pro is powered on, the MCore/Mini-PC will load the Microsoft Windows 11 IoT Enterprise operating system automatically.

Before setting up the ZVC system, you need to connect a mouse to MCore/Mini-PC to complete the initial configuration. We recommend using the wireless mouse kit.



2. Sign in Account


You can use MTouch II to log in the system, the device will automatically enter the Sign in page.

NOTE

- Please contact the corresponding service provider to obtain an account.
- Check whether the device is connected to the Internet. For more information, please refer to [Check Network](#).

1. Click **Sign In** and choose one of the following methods to sign in account:

- **Sign in from Web User Interface**: Use a PC that can access the Internet, enter <https://zoom.us/pair> in the address bar of a browser, and operate according to the on-screen prompts. For more information, please refer to [Zoom](#).
- **Sign in with Email**: On the CTP18, click **Email** and operate according to the on-screen prompts.
- **Sign in with Activation Code**: On the CTP18, click **Activation Code** and contact your Zoom administrator to obtain the activation code. For more information, please refer to [Zoom](#).
- **Sign in with Deployment Code**: On the CTP18, click **Deployment Code** for bulk login. To view the code, go to **Zoom Rooms > Account/Location Settings > Information**(this method can only be used for initial login).



2. Select a room.

3. Check Network

You need to connect the MCore/MCore Pro to the network port by a network cable.

NOTE

If the Mtouch II interface shows that “This device isn’t connected to the Internet”, you need to check whether the network cable is connected correctly.

4. Account Settings

Sign in a Different Account

After logging in to your account for the first time, if you want to switch to another account, you can sign out and then sign in a different account.

In the Zoom Rooms mode, go to **Settings > General > Sign Out**.

Switch Account Mode


By default, the system can switch between two account modes: Zoom Rooms mode and Zoom Rooms Admin mode.

Zoom Rooms mode: Upon system startup, Zoom Rooms mode will automatically log in. You can use your Zoom Rooms account to log in and access basic meeting functions without a password. If you need to configure meeting room settings, you may require an administrator password, depending on whether your system administrator has set one. For more details, please refer to the official Zoom Rooms documentation:

Zoom Rooms Admin mode: The administrator account has the ability to perform any operation on the system but usually requires a password (default password:zoom123). The administrator account is intended solely for managing the ZVC system device and is not necessary for everyday use, such as participating in Zoom Rooms meetings.

- **Switch to Admin mode**


1. In the Zoom Rooms mode, go to **Settings > Windows Settings**.
2. Enter the password (default password:zoom123).



- **Switch to Zoom Rooms mode**

1. In the Admin mode, go to  >  > **ZoomRooms**.

2. Enter the password (default password:zoom123).



5. Check Firmware Version

Check Window Version

In the Admin mode, select  >  and go to **System > About** to view the version of Windows.

Check Zoom Rooms Version

In the Admin mode, select **Settings > About** to view the Zoom Rooms Version.

The screenshot shows the Yealink RoomConnect interface. On the left is the 'Settings' page, and on the right is the 'About' page. A sidebar on the left contains navigation icons for Home, Contacts, Settings (highlighted with a red box and a '1' in a red circle), and About (highlighted with a red box and a '2' in a red circle). The Settings page lists Microphone, Speaker, Camera, Whiteboard Camera, Virtual Background, Advanced, Help, and Lock Settings. The About page lists Zoom Rooms Version (5.14.5 (2778)), Zoom Rooms Chromium Version (110.0.5481.97), Privacy Policy, and Open Source Software. A red box and a '3' in a red circle highlight the Zoom Rooms Version information.

Check Devices Version

1. Switch the Zoom Rooms mode to the Admin mode.
2. Open the Yealink RoomConnect application to select the desired device.
3. Select **Device Status** to check the device firmware version.

The screenshot shows the Yealink RoomConnect web interface. On the left is a navigation menu with options: Return, Device Status, Device Settings, Update Device, and Device Support. The main area displays device information for an MTouchII device. The information is organized into several cards: Equipment Model (MTouchII), Firmware Version (126.410.0.85), Connection Method (Network Cable), Serial Number (803061E020002244), and Hardware Version (126.2.0.0.2.0.17). The Firmware Version card is highlighted with an orange border. At the bottom right, there is a link for the Official Website.


Field	Value
Equipment Model	MTouchII
Firmware Version	126.410.0.85
Connection Method	Network Cable
Serial Number	803061E020002244
Hardware Version	126.2.0.0.2.0.17

6. Update ZVC

Update Windows

Usually, the Windows version will be updated automatically, but you can also check for updates yourself. Before updating, please ensure the device is connected to the Internet and the network is stable. Otherwise, the system update may fail.

1. In the Admin mode, select  to go to **Settings > Update & Security > Windows Update**.
2. Select **Check for update**.



Update Zoom Rooms

You can sign in to the Zoom web portal as an admin to update Zoom Rooms. For usage instructions, please refer to the official Zoom Rooms documentation: [Upgrading or downgrading Zoom Rooms](#).

Update Firmware

Update via Yealink RoomConnect

1. In the Admin mode, open the Yealink RoomConnect application to select the desired device.
2. Go to **Upgrade > Upgrade**.


Y Yealink RoomConnect
⚙️ | — | ✕

← Return



MTouchII

- ☰ Device Status
- 🔧 Device Settings
- 🏠 Update Device
- 🛎️ Device Support



Current version: 126.410.0.85

Your software is up to date

When the device has new firmware available, the device will prompt you to update the firmware

Update Manually

NOTE
 You can also update device firmware in batches through the Yealink Device Management Platform. Please refer to [Firmware Update](#).

7. Test Before Using

Before using the meeting room system, we recommend the administrator do the following to ensure normal use.

Description	Related Document
Test video: Ensure the local images can be displayed usually during the meeting.	Basic Settings
Test audio: Ensure the local audio collection is normal during the meeting.	Audio Collection
Test meeting: Ensure you can enter the meeting usually.	Instant Meeting Join Meeting
Test screen sharing: Ensure you can use the screen sharing usually during the meeting.	Share Content via Cable Share Content via WPP20

FAQ

After the ZVC device is turned on, the MTouch II interface prompts: Please connect to the console to complete the setup?

ZVC system cannot log in to Microsoft Teams?